



### To Print Configuration:

1. Press **STOP**
2. Press **OPTION** to display 101
3. Press **↑ (UP ARROW)** until **701** displays in panel
4. Press **SAVE** to initiate print of configurations



### To Modify Configuration:

1. Press **↑/↓ (UP/DOWN ARROW)** until 1st group number is displayed (e.g., **101, 201, 301**)
2. Press **←/→ (LEFT/RIGHT ARROW)** until exact setting is displayed (e.g., **101, 102, 103**)
3. Press **START** to modify setting
4. Press **←/→ (LEFT/RIGHT ARROW)** until desired setting is displayed (e.g., **2 Dual, 1 Yes**)
5. Press **SAVE** to save setting
6. Press **STOP** to continue to next setting change, or press **STOP**, and **STOP** again to exit

